

No.	Código	Clave	Descripción
1	934862	R1-SOIN-120-160	Correa
2	946592	R2-SOIN-120-160	Jaladera
2.1	934864	R2.1-SOIN-120-160	Tornillo M6x20
2.2	934430	R13.2-SOIN-120-160	Arandela Ø4.5
2.3	934866	R3.1-SOIN-120-160	Tornillo M4x7
2.4	ACC		Arandela Ø4.5
3	946593	R3-SOIN-120-160	Cubierta superior
3.1	946594	R3.1-SOIN-120-160	Tornillo hex. M4x9
3.2	ACC		Tornillo M4x11
3.3	934438	R17.3-SOIN-120-160	Arandela astriada M5
4	946595	R4-SOIN-120-160	Tarjeta de control
5	946596	R5-SOIN-120-160	Panel control
6	946597	R6-SOIN-120-160	Panel frontal
7	946598	R7-SOIN-120-160	Panel frontal
8	946599	R8-SOIN-120-160	Perilla de potenciómetro
9	934873	R9-SOIN-120-160	Conector rápido
10	946600	R10-SOIN-120-160	Panel posterior
10.1	934429	R13.1-SOIN-120-160	Tornillo ST 4x9
10.3	934425	R10.1-SOIN-120-160	Tornillo M4x9
11	946601	R11-SOIN-120-160	Terminal de salida (-)
12	946602	R12-SOIN-120-160	Terminal de salida (+)
13	934877	R13-SOIN-120-160	Soporte 1
14	934878	R14-SOIN-120-160	Soporte 2
14.1	946603	R14.1-SOIN 120-160	Tornillo ST 4x15.5
15	934879	R15-SOIN-120-160	Defector
16	934880	R16-SOIN-120-160	Ventilador
16.1	934432	R14.1-SOIN-100	Tornillo ST5x9
16.2	946604	R16.2-SOIN 120-160	Base para ventilador
17	934881	R17-SOIN-120-160	Interruptor
18	ACC		Protector de Cable
19	934883	R19-SOIN-120-160	Cable de alimentación
20	946605	R20-SOIN 120-160	Tapa trasera
20.1	934436	R17.1-SOIN-100	Tornillo M5x16
20.2	934884	R20-SOIN-120-160	Arnés de tierra
21	934885	R21-SOIN-120-160	Arnés con pinza para electrodo

