


A

No.	Código	Clave	Descripción
1	940104	R1-COMP-80LV	Cárter del motor
2	940105	R2-COMP-80LV	Cigüeñal
3	940106	R3-COMP-80LV	Biela
4	940107	R4-COMP-80LV	Tornillo M8x22 cuerda izquierda
5	940108	R5-COMP-80LV	Junta
6	940109	R6-COMP-80LV	Tapa del cárter
7	940110	R7-COMP-80LV	Sello del tapón
8	940111	R8-COMP-80LV	Mirilla del nivel aceite
9	940112	R9-COMP-80LV	Tornillo M6x16
10	940113	R10-COMP-80LV	Tapón de aceite
11	940114	R11-COMP-80LV	Seguro "C" Ø32
12	940115	R12-COMP-80LV	Perno de pistón
13	940116	R13-COMP-80LV	Pistón
14	940117	R14-COMP-80LV	Set de anillos
16	940118	R16-COMP-80LV	Junta de cilindro
17	940119	R17-COMP-80LV	Cilindro
18	940120	R18-COMP-80LV	Soporte de válvula
19	940122	R19-COMP-80LV	Junta de válvula
20	940121	R20-COMP-80LV	Válvula
21	940123	R21-COMP-80LV	Ensamble de válvula




A



B

No.	Código	Clave	Descripción
26	940124	R26-COMP-80LV	Junta del cilindro superior
27	940125	R27-COMP-80LV	Tapa del cilindro
28	940126	R28-COMP-80LV	Tornillos M7x105
29	940127	R29-COMP-80LV	Conector de descarga
30	940128	R30-COMP-80LV	Filtro de aire
31	940129	R31-COMP-80LV	Capacitor 125 uf, 250 VAC
32	940130	R32-COMP-80LV	Capuchón enroscable
33	940131	R33-COMP-80LV	Arandela ondulada Ø5
34	940132	R34-COMP-80LV	Tornillo M5x105
35	940133	R35-COMP-80LV	Tapa plástica
36	940134	R36-COMP-80LV	Tornillo M5x10
37	940135	R37-COMP-80LV	Tornillo St3.5x12
38	940136	R38-COMP-80LV	Seguro Ø14
39	940137	R39-COMP-80LV	Ventilador
40	940138	R40-COMP-80LV	Tapa del motor
41	940139	R41-COMP-80LV	Estator
42	940140	R42-COMP-80LV	Rodamiento 6202
43	940141	R43-COMP-80LV	Rotor
44	940142	R44-COMP-80LV	Rodamiento 6204
45	940143	R45-COMP-80LV	Sello de aceite 40x20x
48	940144	R48-COMP-80LV	Válvula de salida
49	940145	R49-COMP-80LV	Válvula reguladora de presión
50	940146	R50-COMP-80LV	Presostato



B



C

C

No.	Código	Clave	Descripción
51	940147	R51-COMP-80LV	Válvula de seguridad
52	940148	R52-COMP-80LV	Juego de manómetros
53	940149	R53-COMP-80LV	Tapa
54	940150	R54-COMP-80LV	Tornillos M5x14
55	940151	R55-COMP-80LV	Tubo de descarga
56	940152	R56-COMP-80LV	Válvula antiretorno
57	940153	R57-COMP-80LV	Tubo de alivio
58	940154	R58-COMP-80LV	Tanque
60	940155	R60-COMP-80LV	Rueda
61	940156	R61-COMP-80LV	Tornillo M10x50
62	940157	R62-COMP-80LV	Válvula de drenado
63	ACC		Pata de goma
64	940158	R64-COMP-80LV	Cable y clavija
65	ACC		Mango de hule
66	940159	R66-COMP-80LV	Tornillo M5x6
67	ACC		Arandela de presión M5
69	940160	R69-COMP-80LV	Sello
71	940161	R71-COMP-80LV	Interruptor de sobrecarga 15A, 125/250 VAC

