


A

No.	Código	Clave	Descripción
1	934607	R1-COMP-40LP	Carter del motor
2	934608	R2-COMP-40LP	Cigüeñal
3	934609	R3-COMP-40LP	Biela
4	934610	R4-COMP-40LP	Tornillo M8x22 cuerda izquierda
5	934611	R5-COMP-40LP	Junta
6	934612	R6-COMP-40LP	Tapa del carter
7			
7.1	934613	R7-COMP-40LP	Ens. Tornillo M6x10
8	934615	R8-COMP-40LP	Sello de mirilla
9	934616	R9-COMP-40LP	Mirilla del nivel de aceite
10	934617	R10-COMP-40LP	Tornillo M6x16
11	934618	R11-COMP-40LP	Tapón de aceite
12	934619	R12-COMP-40LP	Seguro "C" Ø
13	934620	R13-COMP-40LP	Perno de pistón
14	934621	R14-COMP-40LP	Pistón
15			
16	934622	R15-COMP-40LP	Juego de anillo para pistón
17	934623	R17-COMP-40LP	Junta de cilindro
18	934624	R18-COMP-40LP	Cilindro
19	934625	R19-COMP-40LP	Arandela de presión Ø8
20	934626	R20-COMP-40LP	Tornillo M8x25
21	934627	R21-COMP-40LP	Junta de válvula
22	934628	R22-COMP-40LP	Ensamble de válvula




A



**B**


No.	Código	Clave	Descripción
25	934629	R25-COMP-40LP	Junta de cilindro
26	934630	R26-COMP-40LP	Cabeza de cilindro
27	934631	R27-COMP-40LP	Filtro de aire
28	934632	R28-COMP-40LP	Tornillo M6x50
29	934633	R29-COMP-40LP	Arandela de presión Ø6
30	934634	R30-COMP-40LP	Codo 3/8x3/8"
31	934635	R31-COMP-40LP	Capacitor 120uF, 250 VAC
32	934636	R32-COMP-40LP	Capuchón
33	934637	R33-COMP-40LP	Arandela de presión
34	934638	R34-COMP-40LP	Tornillo M5x95
35	934639	R35-COMP-40LP	Cubierta de ventilación
36	934640	R36-COMP-40LP	Tornillo de cubierta M5x16
37	934641	R37-COMP-40LP	Seguro C
38	934642	R38-COMP-40LP	Ventilador
39	934643	R39-COMP-40LP	Soporte de motor
40	934644	R40-COMP-40LP	Campo
41	934645	R41-COMP-40LP	Balero de bola 6202
42	934646	R42-COMP-40LP	Rotor
43	934647	R43-COMP-40LP	Balero de bola 6204
44	934648	R44-COMP-40LP	Retén 40x20x7
45	934649	R45-COMP-40LP	Llave de salida de aire
46	934650	R46-COMP-40LP	Regulador de presión
47	934651	R47-COMP-40LP	Presostato
48	934652	R48-COMP-40LP	Válvula de alivio
49	934653	R49-COMP-40LP	Manómetro 18 PSI



**B**

C

No.	Código	Clave	Descripción
50	934654	R50-COMP-40LP	Tubo de conexión
51	934655	R51-COMP-40LP	Manómetro 180 PSI
52	934656	R52-COMP-40LP	Tubo de salida
53	934657	R53-COMP-40LP	Válvula de anti retorno
54	934658	R54-COMP-40LP	Tubo de escape
55	934659	R55-COMP-40LP	Mango
56	934660	R56-COMP-40LP	Tanque
57	934661	R57-COMP-40LP	Tuerca de pata
58	934662	R58-COMP-40LP	Pata de goma
59	934663	R59-COMP-40LP	Tornillo M8x20
60	934664	R60-COMP-40LP	Válvula de drenado 1/4"
61	934665	R61-COMP-40LP	Tornillo M10x50
62	934666	R62-COMP-40LP	Ruedas
63	934667	R63-COMP-40LP	Tuerca
64	934668	R64-COMP-40LP	Cable de alimentación
65	934669	R65-COMP-40LP	Tuerca
66	934670	R66-COMP-40LP	Tornillo M5x6
67	934671	R67-COMP-40LP	Arandela de presión Ø5
68	934672	R68-COMP-40LP	Marca de tierra física
69	934673	R69-COMP-40LP	Protector térmico 15A



C