



A

No.	Código	Clave	Descripción
9M	938257	R9M-FUG-252	Tornillo cbz.allen con ara. plana-pres.
11M	938258	R11M-FUG-252	Tuerca soporte M8
12M	938259	R12M-FUG-252	Ensamble de soporte de arranque
16M	938260	R16M-FUG-252	Retén 12x22x7
17M	938261	R17M-FUG-252	Tapa de carter
18M	938262	R18M-FUG-252	Balero de bolas 6201/P5
19M	938263	R19M-FUG-252	Ensamble de bielea y cigüeñal
20M	938264	R20M-FUG-252	Cuña 3x5x13
21M	938265	R21M-FUG-252	Perno B4x10
22M	938266	R22M-FUG-252	Carter
23M	938267	R23M-FUG-252	Deflector de porteccción
25M	938268	R25M-FUG-252	Tornillo cbz. allen M5x25
26M	938269	R26M-FUG-252	Rotor
27M	938270	R27M-FUG-252	Arandela plana Ø8
28M	938271	R28M-FUG-252	Arandela de presión Ø8
29M	938272	R29M-FUG-252	Tuerca de rotor M8
30M	938273	R30M-FUG-252	Bobina de encendido
30.1M	938274	R30.1M-FUG-252	Arandela aislante
31M	938275	R31M-FUG-252	Arnes electrico
32M	938276	R32M-FUG-252	Tornillo cbz. allen con arandela
33M	938277	R33M-FUG-252	Arandela plana Ø6
34M	938278	R34M-FUG-252	Resorte de clutch
35M	938279	R35M-FUG-252	Patas de clutch
36M	938280	R36M-FUG-252	Arandela ondulada Ø8
37M	938281	R37M-FUG-252	Tornillo especial M6x22
38M	938282	R38M-FUG-252	Carcasa de rotor
39M	938283	R39M-FUG-252	Tornillo cbz. allen con arandela
40M	938284	R40M-FUG-252	Filtro de gasolina
41M	938285	R41M-FUG-252	Balero de agujas
42M	938286	R42M-FUG-252	Seguro de perno
43M	938287	R43M-FUG-252	Pistón
44M	938288	R44M-FUG-252	Perno de pistón
45M	938289	R45M-FUG-252	Junta de carter
46M	938290	R46M-FUG-252	Anillo de pistón



A


No.	Código	Clave	Descripción
B 47M	938291	R47M-FUG-252	Junta de cabeza
48M	938292	R48M-FUG-252	Cilindro
49M	938293	R49M-FUG-252	Tornillo allen M5x18
50M	938294	R50M-FUG-252	Manguera de succión gasolina
51M	938295	R51M-FUG-252	Conector de mangueras
52M	938296	R52M-FUG-252	Carcasa de motor
53M	938297	R53M-FUG-252	Bujía
55M	938298	R55M-FUG-252	Capuchon
57M	938299	R57M-FUG-252	Opresor
58M	938300	R58M-FUG-252	Tapa de bujía
60M	938301	R60M-FUG-252	Junta de escape
61M	938302	R61M-FUG-252	Mofle
63M	938303	R63M-FUG-252	Tornillo cbz allen arandela M5x12
65M	938304	R65M-FUG-252	Tornillo pavonado M5x50
66M	938305	R66M-FUG-252	Tornillo ST2.9x30
67M	938306	R67M-FUG-252	Manguera de retorno gasolina
68M	938307	R68M-FUG-252	Junta de base de carburador
69M	938308	R69M-FUG-252	Tubo de admisión
70M	938309	R70M-FUG-252	Junta de carburador
71M	938310	R71M-FUG-252	Carburador
72M	938311	R72M-FUG-252	Manipulador de acelerador
75M	938312	R75M-FUG-252	Base de filtro
76M	938313	R76M-FUG-252	Tornillo Cromado cbz allen
77M	938314	R77M-FUG-252	Ensamble de sistema de arranque
78M	938315	R78M-FUG-252	Ahogador
79M	938316	R79M-FUG-252	Tornillo cbz. phillips ST4.2x12
80M	938317	R80M-FUG-252	Filtro
81M	938318	R81M-FUG-252	Tapa de filtro
82M	938319	R82M-FUG-252	Tornillo tipo mariposa M4x14
84M	938320	R84M-FUG-252	Tanque de gasolina
85M	938321	R85M-FUG-252	Tapón de gasolina



B

C


No.	Código	Clave	Descripción
1	938322	R1-FUG-252	Tapa de tanque
2	938323	R2-FUG-252	Base de tapón
3	938324	R3-FUG-252	Tapón
4	938325	R4-FUG-252	Sello empaque de tapa
5	938326	R5-FUG-252	Filtro de tanque
6	938327	R6.1-FUG-252	Tanque
6.1	938328	R6.1-FUG-252	Maguera de salida de tanque
6.2	938329	R6.2-FUG-252	Manguera para alimentar
6.3	938330	R6.3-FUG-252	Resorte de manguera
6.4	938331	R6.4-FUG-252	Abrazaderas de manguera
7	938332	R7-FUG-252	Ensamble de bomba
8	938333	R8-FUG-252	Ensamble de correas
9	938334	R9-FUG-252	Sello empaque de tapón
10	938335	R10-FUG-252	Tapón de tanque
11	938336	R11-FUG-252	4 tornillo cbz. phillips
13	938337	R13-FUG-252	Marco
14	938338	R14-FUG-252	Grapas
15	938339	R15-FUG-252	Respaldo
16	938340	R16-FUG-252	Tuerca M8
17	938341	R17-FUG-252	Arandela de presión M8
18	938342	R18-FUG-252	Ensamble de control de acelerador



C

D

No.	Código	Clave	Descripción
21	948343	R21-FUG-252	Tuerca M6
23	948344	R23-FUG-252	Tornillo cbz hex. arandela M6x20
24	948345	R24-FUG-252	Chicote de aceleración
25	948346	R25-FUG-252	Arnés de tierra
26	948347	R26-FUG-252	Tuerca M20
27	948348	R27-FUG-252	Amortiguador 6x44
28	948349	R28-FUG-252	Placa de conexiones
29	948350	R29-FUG-252	Boquilla doble
30	948351	R30-FUG-252	Soporte
31	948352	R31-FUG-252	Soporte derecho
32	948353	R32-FUG-252	Soporte izquierdo
33	948354	R33-FUG-252	Boquilla ajustable
34	948355	R34-FUG-252	Tubo pulverizador recto
35	948356	R35-FUG-252	Sello empaque Ø11
36	948357	R36-FUG-252	Válvula
37	948358	R37-FUG-252	Mango
38	948359	R38-FUG-252	Manguera flexible
39	948360	R39-FUG-252	Amortiguador 6x68
40	948361	R40-FUG-252	Conector T
41	948362	R41-FUG-252	Conector



D

