


A

No.	Código	Clave	Descripción
1	933948	R1-ENNE-120	Tornillo M4x14
2	933949	R2-ENNE-120	Buje
3	933950	R3-ENNE-120	Escape de aire
4	933951	R4-ENNE-120	Tornillo M5x22
5	933952	R5-ENNE-120	Sello 7.8x1.9
6	933953	R6-ENNE-120	Tapa de cilíndrica
7	933954	R7-ENNE-120	Calza
8	933955	R8-ENNE-120	Sello 13.6x2.4
9	933956	R9-ENNE-120	Empaque de cilindro
10	933957	R10-ENNE-120	Resorte de compresión
11	933958	R11-ENNE-120	Pistón
12	933959	R12-ENNE-120	Sello 33x2.7
13	933960	R13-ENNE-120	Sello 28x3.4
14	933961	R14-ENNE-120	Sello 14x3.4
15	933962	R15-ENNE-120	Sello 40.9x2.3
16	933963	R16-ENNE-120	Collarín de soporte
17	933964	R17-ENNE-120	Sello 32.4x2.3
18	933965	R18-ENNE-120	Cilindro
19	933966	R19-ENNE-120	Sello 25x2.9
20	933967	R20-ENNE-120	Pistón guía
21	933968	R21-ENNE-120	Tope
22	933969	R22-ENNE-120	Mango
23	933970	R23-ENNE-120	Cuerpo
24	933971	R24-ENNE-120	Sello 35x3.5
25	933972	R25-ENNE-120	Tapa final




A



B


No.	Código	Clave	Descripción
26	933973	R26-ENNE-120	Coenctor de entrada de aire
27	933974	R27-ENNE-120	Boquilla
28	933975	R28-ENNE-120	Guía de seguridad
29	933976	R29-ENNE-120	Resorte
30	933977	R30-ENNE-120	Soporte de seguridad
31	933978	R31-ENNE-120	Ajustador
32	933979	R32-ENNE-120	Seguro U
33	933980	R33-ENNE-120	Impulsor
34	933981	R34-ENNE-120	Punta de no marcas
35	933982	R34.1-ENNE-120	Sello 1.2x1.9
36	933983	R36-ENNE-120	Perno 3x26
37	933984	R37-ENNE-120	Pasador 3x26
38	933985	R38-ENNE-120	Resorte
39	933986	R39-ENNE-120	Placa de gatillo
40	933987	R40-ENNE-120	Cuerpo de gatillo
41	933988	R41-ENNE-120	Perno 2.5x17
42	933989	R42-ENNE-120	Sello 12.5-8.1.5
43	933990	R43-ENNE-120	Válvula de gatillo
44	933991	R44-ENNE-120	Resorte
45	933992	R45-ENNE-120	Sello 2.2x1.5
46	933993	R46-ENNE-120	Vástago de válvula
47	933994	R47-ENNE-120	Guía de válvula
48	933995	R48-ENNE-120	Sello 11.2x1.9
49	933996	R49-ENNE-120	Tuerca M5
50	933997	R50-ENNE-120	Tornillo M5x20



B

C

No.	Código	Clave	Descripción
51	933998	R51-ENNE-120	Cubierta trasera
52	933999	R52-ENNE-120	Tornillo M4x10
53	934000	R53-ENNE-120	Tuerca M4
54	934001	R54-ENNE-120	Tornillo M4x6
55	934002	R55-ENNE-120	Seguro de fijador
56	934003	R56-ENNE-120	Soporte de riel
57	934004	R57-ENNE-120	Tornillo M4x8
58	934005	R58-ENNE-120	Cargador móvil
59	934006	R59-ENNE-120	Tornillo M4x12
60	934007	R60-ENNE-120	Guía de controlador
61	934008	R61-ENNE-120	Perno 3x18
62	934009	R62-ENNE-120	Perno 3x14.8
63	934010	R63-ENNE-120	Espaciador
64	934011	R64-ENNE-120	Guía de controlador
65	934012	R65-ENNE-120	Arandela de presión
66	934013	R66-ENNE-120	Ensamble de pasador de liberación
69	934014	R69-ENNE-120	Cargador fijo
70	934015	R70-ENNE-120	Resorte
71	934016	R71-ENNE-120	Resorte de compresión
72	934017	R72-ENNE-120	Porta resorte
73	934018	R73-ENNE-120	Propulsor de clavos



C