


**A**


No.	Código	Clave	Descripción
A1	943185	RA1-GEN70P	Tornillo especial M6x61
A2	943186	RA2-GEN70P	Arandela
A3	943187	RA3-GEN70P	Empaque
A4	943188	RA4-GEN70P	Tubo de respiración
A5	943189	RA5-GEN70P	Tapa de punterías
A6	943190	RA6-GEN70P	Junta de tapa
A7	943191	RA7-GEN70P	Tornillo M10x80
A8	943192	RA8-GEN70P	Bujía
A9	943193	RA9-GEN70P	Tornillo sin fin M6x8x106
A10	943194	RA10-GEN70P	Tornillo sin fin 8x32
A11	943195	RA11-GEN70P	Junta de cabeza de cilindro
A12	943196	RA12-GEN70P	Buje
A13	943197	RA13-GEN70P	Cabeza de cilindro



**A**

**B**


B1	943198	RB1-GEN70P	Cárter
B2	943199	RB2-GEN70P	Seguro
B3	943200	RB3-GEN70P	Retén
B4	943201	RB4-GEN70P	Seguro
B5	943202	RB5-GEN70P	Barra de gobernador
B6	943203	RB6-GEN70P	Retén Ø35x+Ø52x8
B7	943204	RB7-GEN70P	Abrazadera
B8	943205	RB8-GEN70P	Tornillo M6x12
B9	943206	RB9-GEN70P	Alerta de aceite
B10	943207	RB10-GEN70P	Tornillo drena M12x1.5
B11	943208	RB11-GEN70P	Arandela 12x20x1.5
B12	943209	RB12-GEN70P	Balero de bolas 6207
B13	943210	RB13-GEN70P	Balero de bolas 6202
B14	943211	RB14-GEN70P	Interruptor de nivel de aceite
B15	943212	RB15-GEN70P	Tornillo M6x14
B16	943213	RB16-GEN70P	Buje



**B**


C

No.	Código	Clave	Descripción
C1	943214	RC1-GEN70P	Tapa de cárter
C2	943215	RC2-GEN70P	Tornillo M8x40
C3	943256	RC3-GEN70P	Retén 35x52x8
C4	943217	RC4-GEN70P	Ensamble de bayoneta
C5	943218	RC5-GEN70P	Arandela 6.2x13x1
C6	943219	RC6-GEN70P	Gobernador
C7	943220	RC7-GEN70P	Eje
C8	943221	RC8-GEN70P	Camisa de eje
C9	943222	RC9-GEN70P	Balero de bolas 6207
C10	943223	RC10-GEN70P	Balero de bolas 6202
C11	943224	RC11-GEN70P	Junta de cárter




D

D1	943225	RD1-GEN70P	Eje de balance
D2	943226	RD2-GEN70P	Cigüeñal
D3	943227	RD3-GEN70P	Ensamble de biela
D4	943228	RD4-GEN70P	Seguro de pistón
D5	943229	RD5-GEN70P	Perno de pistón
D6	943230	RD6-GEN70P	Pistón
D7	943231	RD7-GEN70P	Set de anillos de pistón







E

E1	943232	RE1-GEN70P	Tuerca
E2	943233	RE2-GEN70P	Pivote oscilación balancín
E3	943234	RE3-GEN70P	Balancín
E4	943235	RE4-GEN70P	Pivote de perno
E5	943236	RE5-GEN70P	Placa guía
E6	943237	RE6-GEN70P	Varilla de empuje 1
E7	943238	RE7-GEN70P	Elevador de válvula
E8	943239	RE8-GEN70P	Árbol de levas
E9	943240	RE9-GEN70P	Rotador
E10	943241	RE10-GEN70P	Retenedor de muelle
E11	943242	RE11-GEN70P	Resorte



No.	Código	Clave	Descripción	
<b>F</b>	F1	943247	RF1-GEN70P	Tornillo especial M6x8
	F2	943248	RF2-GEN70P	Sistema de arranque
	F3	943249	RF3-GEN70P	Tornillo M6x12
	F4	943250	RF4-GEN70P	Cubierta de ventilador
	F5	943251	RF5-GEN70P	Abrazadera de cable
	F6	943252	RF6-GEN70P	Tolva
	F7	943253	RF7-GEN70P	Tornillo M6x12
<b>G</b>	G1	943254	RG1-GEN70P	Junta de base carburador
	G2	943255	RG2-GEN70P	Base de carburador
	G3	943256	RG3-GEN70P	Junta de carburador
	G4	943257	RG4-GEN70P	Ensamble de carburador
<b>H</b>	H1	943258	RH1-GEN70P	Tuerca especial M16
	H2	943259	RH2-GEN70P	Polea de arranque
	H3	943260	RH3-GEN70P	Aspas de ventilador
	H4	943261	RH4-GEN70P	Volante
	H5	943262	RH5-GEN70P	Tornillo M6x25
	H6	943263	RH6-GEN70P	Soporte de tensión
	H7	943264	RH7-GEN70P	Tornillo M6x25
	H8	943265	RH8-GEN70P	Bobina de encendido
	H9	943266	RH9-GEN70P	Tornillo M6x25
	H10	943267	RH10-GEN70P	Supresor de ruido
<b>I</b>	I1	943268	RI1-GEN70P	Tornillo M8x35
	I2	943269	RI2-GEN70P	Marcha



J

No.	Código	Clave	Descripción
J1	943270	RJ1-GEN70P	Base de gobernador
J2	943271	RJ2-GEN70P	Resorte de aceleración
J3	943272	RJ3-GEN70P	Barra de aceleración
J4	943273	RJ4-GEN70P	Brazo de gobernador
J5	943274	RJ5-GEN70P	Tornillo especial M6x21
J6	943275	RJ6-GEN70P	Tuerca M6
J7	943276	RJ7-GEN70P	Resorte de retorno
J8	943277	RJ8-GEN70P	Tornillo M6x12

K



K1	943278	RK1-GEN70P	Ensamble de filtro de aire
K2	943279	RK2-GEN70P	Filtro

L


L1	943280	RL1-GEN70P	Junta de mofle
L2	943281	RL2-GEN70P	Mofle
L3	943282	RL3-GEN70P	Tuerca M8
L4	943283	RL4-GEN70P	Soporte de mofle
L5	943284	RL5-GEN70P	Tornillo M8x12
L6	943285	RL6-GEN70P	Tornillo M8x16
L7	943286	RL7-GEN70P	Tablero de aislamiento
L8	943287	RL8-GEN70P	Tornillo M6x12

M


M1	943288	RM1-GEN70P	Tanque de gasolina
M2	943289	RM2-GEN70P	Tapón de tanque
M3	943290	RM3-GEN70P	Filtro de gasolina
M4	943291	RM4-GEN70P	Flotador de gasolina
M5	943292	RM5-GEN70P	Tornillo M6x22
M6	943293	RM6-GEN70P	Válvula de paso
M7	943294	RM7-GEN70P	Manguera 5x9
M8	943295	R8M-GEN70P	Abrazadera
M9	943296	RM9-GEN70P	Soporte de tanque
M10	943297	RM10-GEN70P	Buje
M11	943298	RM11-GEN70P	Arandela
M12	943299	RM12-GEN70P	Tornillo M6x22



K



L



M





**N**

No.	Código	Clave	Descripción
N1	943300	RN1-GEN70P	Panel frontal
N2	943301	RN2-GEN70P	Cubierta trasera
N3	943302	RN3-GEN70P	Tornillo M6x12
N4	943303	RN4-GEN70P	Chapa de encendido
N5	943304	RN5-GEN70P	Protector
N6	943305	RN6-GEN70P	Voltímetro
N7	943306	RN7-GEN70P	Interruptor de voltaje
N8	943307	RN8-GEN70P	Interruptor de seguridad
N9	943308	RN9-GEN70P	Contactos 20A/ 125V
N10	943309	RN10-GEN70P	Contacto 30A/ 240V
N11	943310	RN11-GEN70P	Protector térmico
N12	943311	RN12-GEN70P	Terminales (+)(-)
N13	943312	RN13-GEN70P	Tornillo M6x18
N14	943313	RN14-GEN70P	Arandela 6x12x0.9
N15	943314	RN15-GEN70P	Arandela de presión 6
N16	943315	RN16-GEN70P	Tuerca M6
N17	943316	RN17-GEN70P	Arnés maestro
<b>P1</b>	<b>RP1-GEN70P</b>	<b>Ensamble de motor</b>	
P2	943317	RP2-GEN70P	Cable de corriente +
P3	943318	RP3-GEN70P	Cubierta de ventilador
P4	943319	RP4-GEN70P	Soporte



**P**


**N**



**P**



No.	Código	Clave	Descripción
Q1	943320	RQ1-GEN70P	Rotor
Q2	943321	RQ2-GEN70P	Campo
Q3	943322	RQ3-GEN70P	Tapa de motor
Q4	943323	RQ4-GEN70P	Tuerca M5
Q5	943324	RQ5-GEN70P	Arandela 5
Q6	943325	RQ6-GEN70P	Tornillo M5x220
Q7	943326	RQ7-GEN70P	Arandela 10
Q8	943327	RQ8-GEN70P	Arandela de presión 10
Q9	943328	RQ9-GEN70P	Tornillo M10x270
Q10	943329	RQ10-GEN70P	Tornillo 6x185
Q11	943330	RQ11-GEN70P	Carbón
Q12	943331	RQ12-GEN70P	Tornillo M5x20
Q13	943332	RQ13-GEN70P </td <td>Puente rectificador</td>	Puente rectificador
Q14	943333	RQ14-GEN70P	Tabla de conexiones
Q15	943334	RQ15-GEN70P	Regulador de voltaje
Q16	943335	RQ16-GEN70P	Tornillo M5x16
Q17	943336	RQ17-GEN70P	Tapa trasera de generador
Q18	943337	RQ18-GEN70P	Tornillo M5x12



S

No.	Código	Clave	Descripción
S1		RS1-GEN70P	Marco
S2	943338	RS2-GEN70P	Tornillo M6x12
S3	943339	RS3-GEN70P	Amortiguador izquierdo
S4	943340	RS4-GEN70P	Amortiguador derecho
S5	943341	RS6-GEN70P	Arandela Ø10
S6	943342	RS7-GEN70P	Arandela Ø10
S7	943343	RS8-GEN70P	Tuerca M10
S8		RS9-GEN70P	Batería
S9	943344	RS10-GEN70P	Ganchos
S10	943345	RS11-GEN70P	Solera
S11	943346	RS12-GEN70P	Tuerca M6
S12	943347	RS13-GEN70P	Tornillo M8x50
S13	943348	RS14-GEN70P	Arandela Ø9XØ30
S14	943349	RS15-GEN70P	Palanca
S15	943350	RS16-GEN70P	Tuerca 86
S17	943351	RS18-GEN70P	Soporte de patas
S18	943352	RS19-GEN70P	Tornillo M8x20
S20	943353	RS21-GEN70P	Patas
S21	943354	RS22-GEN70P	Ruedas inflables
S22	943355	RS23-GEN70P	Tuerca M12
S23	943356	RS24-GEN70P	Arandela Ø12
S24	943357	RS25-GEN70P	Arandela plana Ø12
S25	943358	RS26-GEN70P	Flecha



S

